



# PLM Passwords

2 September, 2010

New with PLM v4.76 we have changed the user interface regarding passwords. Passwords are set with the Programming Tool and can have a Maximum length of 16 characters per Password.

For the DVC7 & DVC10, passwords are:

- Level 0: is a monitor only status
- Level 1: Send Password, allows the user to change EE-Mem values.
- Level 2: App Password, allows level 1, changes to PLM, and loading an Application.
- Level 3: Bios Password, allows level 1, level 2, and loading a Bios.

If there are no passwords in the program, The PLM4.76 will default to a level 2.

If the installed program has a password, the End User will have level 0 access until the appropriate password is entered in the PLM.

For the DVC50, passwords are:

- Level 1: OEM = Send EE-mem
- Level 2: APPLICATION = Load Application
- Level 3: BIOS = Load Bios

Programming Tool for the DVC7 & DVC10 for reference.

