



S35 Color Display

Installation Manual

In order to consistently bring you the highest quality, full-featured products, we reserve the right to change our specifications and designs at any time. The latest version of this manual can be found at enovationcontrols.com.

Warranty - A limited warranty on materials and workmanship is given with this Enovation Controls product.

A copy of the warranty may be viewed or printed by going to www.enovationcontrols.com/warranty



BEFORE BEGINNING INSTALLATION OF THIS ENOVATION CONTROLS PRODUCT:

Read and follow all installation instructions.

Please contact Enovation Controls immediately if you have any questions.

Table of Contents

Hardware Installation	5
Inspecting Package Contents	5
Product Dimensions	5
Dash-Mounted Installation	6
Wiring Information	7
Pin Out Specifications	7
S35 Mating Connector Part Numbers	8
S35 Wiring Diagram	8
Configuration and Programming Information	9
Application Update Procedure	9
Specifications	12

THIS PAGE INTENTIONALLY LEFT BLANK

Hardware Installation

The following instructions will guide you through installing the S35 color display. The S35 Operations Manual and this installation manual can be found by scanning the QR code on the product package or online at: Support.enovationcontrols.com, then search for S35.


Inspecting Package Contents


It is recommended that you ensure all parts are accounted for and inspect each item for damage (which may occur during shipping) before attempting to install the product. The items included in the box are:


1 – S35 Color display with attached screw-on ring clamp

Product Dimensions

Measurements shown in inches [mm]







Dash-Mounted Installation

Tools needed.

- Jig saw or
- 2" Hole saw or
- 2" knockout (chassis) punch


Preparing the Dash

- 1. Determine the location where the S35 will be placed into the dash. Refer to the Mounting Hole Options section next for appropriate hole opening size.
- 2. Measure twice, cut once! Cut the hole into the dash where the S35 will reside.

Mounting the Unit

- 1. Remove the screw-on mounting clamp ring from the back of the display.
- 2. Place the backside of the display through the opening in the dash.
- 3. Push the unit through the opening until the back of the case is flush with the panel.
- 4. Place the screw-on mounting clamp ring behind the panel and screw onto unit until hand-tight.

Mounting Hole Options



Wiring Information

Pin Out Specifications




A B							
A CONNECTOR PINOUT		30	04	30	04	B CONNECTOR PINOUT	
PIN	FUNCTION	20	05	20	05	PIN	FUNCTION
1	V+ Power	10	06	10	06	1	DIGITAL OUT 1
2	CAN-HI	\neg	_/	_	/	2	DIGITAL OUT 2
3	CAN-LO					3	RS485+
4	FREQ IN					4	RS485-
5	ANALOG IN 1					5	ANALOG IN 2
6	GND					6	ANALOG GND

S35 Mating Connector Part Numbers

- Deutsch DT06-6S plug housing
- W6S Wedge locks
- Deutsch 0462-201-16141 contact (socket)

S35 Wiring Diagram




Configuration and Programming Information


Application Update Procedure

This section demonstrates the process of updating a new application on the S35 Color Display.

Installation from a USB Flash Drive

Prior to installation from a USB flash drive, ensure that your USB flash drive is formatted using the default size allocation. For best results, place just a single application install file on the US flash drive.





Continued

Step	Action
8	If "Install Software Update" is accepted in Step 6, "Erasing Flash" will be displayed. FINOURTION CONTROLS BOOTFORM OF THE REVICE DURNING UPDATE A
9	After the internal flash is erased, the new application will get written into flash memory. FIGURATION CONTROLS BOOKDAFFTHE SEVICE SUMMO UPGATE A
10	Once the installation is complete, the bootloader will switch to the main application. FIGURATION CONTROLS BOOTLOAGE OF THE DEVICE GURNO APPORTED A DO NOT FORCE OF THE DEVICE OF T
NOTE:	Do not turn off the power after accepting a software installation update.

Specifications

Computing	Computing					
Main Processor:	Arm 32-bit Cortex-M4 CPU 120 MHz +FPU					
Internal Storage	2048 kB					
RAM	640 kB					
Storage:	4096 kB					
Display/HMI						
Screen:	3.5-inch, 18-bit Color LCD TFT					
Resolution:	320 x 240					
Brightness:	800 cd/m ²					
Interfaces						
CAN:	1x CAN 2.0B (Selectable 250k/500k/1Mb baud rate)					
Serial:	1x RS485 – Half duplex					
USB:	1x USB-C 2.0b					
Electrical						
Operating Volts:	6-36 VDC, reverse polarity protected					
Digital Outputs:	2x low-side open drain 500 mA					
Analog Inputs:	2x user configurable (0-5 V, 4-20mA, Resistive) 1x internal battery voltage sensing (0-36V)					
Real Time Clock:	Yes, (with 7-day backup)					
Environmental						
Operating Temp:	-40°C to +85°C (-40°F to +185°F)					
Storage Temp:	-40°C to +85°C (-40°F to +185°F)					
Protection:	IP67 1EC 60529					
Vibration:	ISO 16750					
Shock:	ISO 16750					
EMC/EMI:	ISO 13766, ISO 14982					

How to Order

The following S35 Color Display and accessories are available through Enovation Controls:

Part Number	Description	Order Details
78700727	S35 Color Display	Display
78900727	S35 Color Display (24 Pack)	Bulk Pack Display

- THIS PAGE INTENTIONALLY LEFT BLANK -

- THIS PAGE INTENTIONALLY LEFT BLANK -

In order to consistently bring you the highest quality, full-featured products, we reserve the right to change our specifications and designs at any time. MURPHY products and the Murphy logo are registered and/or common law trademarks of Enovation Controls, LLC. This document, including textual matter and illustrations, is copyright protected by Enovation Controls, LLC, with all rights reserved. (c) 2023 Enovation Controls, LLC. A copy of the warranty may be viewed or printed by going to www.enovationcontrols.com/warranty

ENOVATION CONTROLS CORPORATE HEADQUARTERS 5311 S 122ND EAST AVENUE TULSA, OK 74146

ENOVATION CONTROLS LTD. – UNITED KINGDOM CHURCH ROAD LAVERSTOCK SALISBURY SP1 10Z UK

SUN MURPHY INTERNATIONAL TRADING (SHANGHAI) CO., LTD B15 ROOM, 6# BUILDING, 351 SIZHUAN ROAD SONGJIANG DISTRICT, SHANGHAI 201601, CHINA

ENOVATION CONTROLS INDIA PVT. LTD. PLOT NO. 146, SECTOR 10, PCNTDA BHOSARI, PIMPRI CHINCHWAD PUNE - 411026 MAHARASHTRA, INDIA

U.S. SALES & SUPPORT

PHONE: 918 317 4100 EMAIL: SALES@ENOVATIONCONTROLS.COM WWW.ENOVATIONCONTROLS.COM

CONTACT US



INTERNATIONAL SALES & SUPPORT

EUROPE, MIDDLE EAST, AFRICA PHONE: +44 1722 410055 EMAIL: EMEASALES@ENOVATIONCONTROLS.COM

CHINA
PHONE: +86 21 6237 5885
EMAIL: APACSALES@ENOVATIONCONTROLS.COM

INDIA PHONE: +91 91581 37633 EMAIL: INDIASALES@ENOVATIONCONTROLS.COM





1022QAP07 (India)